


Cross beam adaptors - T4

Accessories:




Center pick up points:

Standard (inches)




Wide (inches)




T4-1 / T4-1W

Both saddles slide independently




T4-2 / T4-2W

Both saddles slide independently




Cross beam adaptors - T5

Accessories:




Center pick up points: Standard (inches)



T5-1 Cross beam

Both halves with saddles slide out independently



T5-2 Cross beam closed



T5-2 Cross beam open




Cross beam adaptors - T6

Accessories:




Center pick up points:


Standard (inches)



Wide (inches)



T6-1 Cross beam closed



T6-2 Cross beam open

Turn wheel and both saddles move in & out simultaneously

